

Changing your Code

- 1 Open the keysafe and leave the dials on your current code.
- 2 Push the RESET button from A to B.




- 3 Set your new code on the dials.
- 4 Push RESET back to A.

NOTE: If you have a Professional Response Plan, it is important to notify us if you change your keysafe code.

Your Umps Keysafe

Your keysafe lets emergency services or nominated contacts access your home if needed. They can use the code to unlock it and get a key.

Your keysafe code is:



To change the code, see the back of this booklet.

✉ support@umps.com

☎ 1300 907 272 (Australia)

☎ 0800 005 687 (New Zealand)

Installation

Option 1: Shackle

Insert the shackle into the two holes on top of the key safe.



To remove, open the key safe and slide the release tab left.



Option 2: Wall Mounted

1 Hold in position and mark holes with a pencil.



2 Fix to wall using provided screws and plugs. You may need to use a masonry drill for some surfaces.

NOTE: If you have a Professional Response Plan, contact us after installing your Keysafe to provide us with its location.